

## Technical Data – RS 485-IS Barrier (101-201410)

Technical Data – RS 485-IS Barrier (101-201410)	
<b>Backplane</b>	
PROFIBUS networks Modules Power supply Current consumption at 5.72 VDC  Compatible backplane units	4 (set by dipswitches or web server) 10 (positioned in the first 10 slots) Provided through the backplane ± 450 mA (750 mA max) At this current consumption the module is switched OFF from backplane. Occurs when module is faulty, e.g. internal short circuit. 101-200011, 101-200012, 101-200023, 101-200024, 101-200027
<b>Protocol specifications</b>	
Supported Protocols	DP-V0, DP- V1, DP-V2, FDL, MPI, FMS, PROFIsafe, PROFIdrive and any other FDL based protocol
Address	No bus address required
Transmission speed	9.6 kbps .. 1.5 Mbps (including 45.45 kbps)
Transmission speed detection	Auto detect (< 10 s detection and 50 s lost time)
Data delay time (normal mode)	2.0 TBit
Data delay time (redundant mode)	12.0 TBit
Delay time jitter	Max. ¼ TBit
<b>Oscilloscope specifications</b>	
Frequency Resolution Differential range	192 MS/s 27 mV -3.49..+3.49 V
<b>PROFIBUS cable specifications</b>	
Cable lengths	1200 m at 9.6 kbps .. 93.75 kbps 1000 m at 187.5 kbps 400 m at 500 kbps 200 m at 1.5 Mbps
Wire diameter (for the screw terminals) Wire type Number of devices Required termination	< 1.5 mm <sup>2</sup> Stranded or solid core Maximum 31 devices per channel (busloads) DB9-IS connector with internal 200Ω only
Redundancy	Yes, maximum 10 cables activated by switch

Technical Data – RS 485-IS Barrier (101-201410)	
<b>Dipswitches</b>	
<p>NW0 NW1 LEFT LEFT RIGHT LEFT LEFT RIGHT RIGHT RIGHT</p> <p>RED LEFT / RIGHT</p> <p>H/S LEFT / RIGHT</p>	<p><b>PROFIBUS Network</b></p> <p>1 2 3 4</p> <p><b>Redundancy</b> OFF / ON</p> <p><b>Settings</b> Hardware / Software</p>
<b>ATEX (electrical)</b>	
<p>Uo Io Ui Li Ci Output characteristic</p>	<p>4.2 V 149 mA ≥ 4.2 ≈ 0 μH V Negligibly small Linear</p>
<b>ATEX (compliance):</b>	
<p>II (2) G [Ex ia Gb] IIC EN-IEC60079-0: 2009 / EN-IEC60079-11: 2012 / EN-IEC60079-25: 2010 PROFIBUS International IS Installation Guidelines Certification number: <b>DEKRA 12ATEX0192</b></p>	
<b>LEDs</b>	
<p>RDY RX HWE ER MIN TERM</p>	<p>Module is ready for operation (ON) Receiving telegrams (blinking) Internal repeater error (contact PROCENTEC) No or bad telegrams detected Signal amplitude of the telegrams too low (&lt; 1.64 V) Idle voltage too low ( &lt;0.35 V .. &gt;0.75 V ) <i>Alarm values can be changed through the web server.</i></p>
<b>Others</b>	
<p>Head Station firmware Operating temperature Weight</p>	
<p><b>PROCENTEC</b> Klopperman 16 2292 JD WATERINGEN (NL)</p>	<p><b>Tel.: +31-174-671800</b> <b>Fax: +31-174-671801</b> <b>Email: info@procentec.com</b></p>